

Guide for Using the Equipment in VAC 005

Room Equipment: HDTV; Document Camera; VHS/DVD player; 27" iMac; cabling to connect a laptop computer
Doc Camera must be turned on to display images on the TV.


All equipment in this room is connected to the HDTV.

Location of Remote Controls : HDTV -on the Teaching Station; VHS/DVD - tethered to player

1. If using your laptop: Start with laptop turned off.

For computer image to be displayed,

securely connect three (3) cables on top of teaching station to laptop labeled 1) LAPTOP Network 2) LAPTOP Video 3) LAPTOP Audio



2. Turn on the HDTV


Remote is tethered on the Teaching Station

3. Turn on the Desktop Computer, log in, and wait as it communicates with the HDTV.

The computer image will be displayed on the TV screen.

4. Press POWER button on the Document Camera. The Doc Camera controls all image displays.

Press and hold until it turns Blue.



To display **Document Camera image** > Press the button labeled > **CAM / PC1 / PC2** displays lighted blue circle when selected (see graphic above)
Light Control Button will adjust lighting (see graphic above)

To display **Desktop computer image** > Press the button labeled > **CAM / PC1 / PC2** displays lighted green circle when selected (see graphic above)
A laptop connection will be viewed using the **PC2** input

To display **VHS/DVD image** > Turn player on and load/play video.

Press the button labeled > **HDMI / VIDEO**

displays lighted green circle when selected (see graphic above)

Button on center, front of VHS/DVD player controls video input; select VCR or DVD

Remote for VHS/DVD is tethered alongside player



5. POWER OFF

1) Desktop computer 2) Document Camera 3) VHS/DVD Player and/or 4) Laptop & disconnect cables

Need assistance? Please contact Becki George, Learning Technology Coordinator, x.1268